



## Dimensions

(not for construction unless certified) – dimensions in mm (in.)

### 266HSH Transmitter with barrel housing - 1/2 NPT female connection for sensor P, Q and S





### 266HSH Transmitter with barrel housing - 1/2 in. NPT female connection for sensor W



### ...Dimensions

(not for construction unless certified) – dimensions in mm (in.)

266HSH Transmitter with barrel housing - 1/2 NPT male connection for sensor P, Q and S



266HSH Transmitter with barrel housing - 1/2 NPT male connection for sensor W

